

AURUM

Basic Features & User Guide



ACTIVATING THE VAPE

1. Attach the cartridge by threading it on to the top of the battery and lightly hand-tighten to secure.
2. Click 5 times rapidly to turn the device on / off.

HEAT SETTINGS

Aurum has 3 specific heat settings:

1. The settings are: low (white), medium (blue) and high (red).
2. To cycle through these, please click the button 3 times rapidly. The LED light around the button will indicate the heat setting you have selected: (low, medium, high).
3. Starseed always recommends starting with the lowest setting and increase heat settings from there as so desired.

PRE-HEATING

When vaping in colder weather it is recommended that you pre-heat your oil before use.

1. Click the button 2 times quickly to activate the 15 second preheat function. The LED light around the button will light up and remain on for the duration.
2. You can always cancel or stop the pre-heat cycle by clicking the button once.
3. Preheat function can also loosen/dislodge any clogs, enhancing the user experience

SAFETY

1. Store device vertically and at room temperature for best performance
2. Overheat Protection: For your protection the battery will shut off after 10 seconds of no use.
3. Certification: RoHS, CE / EMC, FCC, Prop 65, UL, UL listed Cell/PCB/Wire, MSDS

